



IMPORTANT!!!

GUNS WILL NOT FUNCTION PROPERLY,
if marquee is not placed and connected correctly.

Marquee sits on top of monitor. Not in front of and not behind.

Front of marquee sits flush with front of monitor. Marquee tab is flush against monitor face.



Marquee tab is centered within monitor face.



MUST BE
FLUSH!!!!

Connect IR marquee 6-pin connector at top of stanchion.

